


## 1/2" AIR IMPACT WRENCH (Twin Hammer)



UNIT PRICE (US\$/PC) (FOB Taiwan)	INDEX NO.	PARTS NO.	DESCRIPTION	Q'TY
0.4	1	RH4002TA01	C-Ring	1
0.3	2	RH4002TA02	Screw	4
5.5	3	RH4002TA03	Hammer Case	1
0.2	4	RH4002TA04	O-Ring	1
3.6	5	RH4002TA05	Bushing	1
0.2	6	RH4002TA06	Anvil Collar	1
0.2	7	RH4002TA07	O-Ring	1
9.7	8	RH4002TA08	Anvil	1
0.4	9	RH4002TA09	Hammer Pin	2
11.7	10	RH4002TA10	Hammer Cage	1
6.5	11	RH4002TA11	Hammer Dog	2
1	12	RH4002TA12	Front Gasket	1
15.7	13	RH4002TA13	Motor Housing	1
0.3	14	RH4002TA14	O-Ring	1
1.4	15	RH4002TA15	Ball Bearing	1
3.9	16	RH4002TA16	Front Plate	1
0.7	17	RH4002TA17	Front Plate Washer	1
5.9	18	RH4002TA18	Cylinder	1
0.2	19	RH4002TA19	Spring Pin	1
7.1	20	RH4002TA20	Rotor	1
0.3	21	RH4002TA21	Rotor Blade	8
0.7	22	RH4002TA22	Rear Plate Washer	1
4.5	23	RH4002TA23	Rear Plate	1
1.3	24	RH4002TA24	Ball Bearing	1
4.7	25	RH4002TA25	Reverse Valve	1
0.2	26	RH4002TA26	O-Ring	1

Consumable parts No. 4, 6, 7, 12, 23, 28, 30, 36, 48

INDEX NO.	PARTS NO.	DESCRIPTION	Q'TY	UNIT PRICE (US\$/PC) (FOB Taiwan)
27	RH4002TA27	Rear Gasket	1	1
28	RH4002TA28	Rear Cover	1	3.6
29	RH4002TA29	Screw	4	0.3
30	RH4002TA30	Steel Ball	1	0.2
31	RH4002TA31	Spring	1	0.2
32	RH4002TA32	Screw	1	0.3
33	RH4002TA33	Reverse Lever	1	0.6
34	RH4002TA34	Valve Block Gasket	1	0.4
35	RH4002TA35	Spring Pin	2	0.2
36	RH4002TA36	Turn Base	1	7.2
37	RH4002TA37	Screw	2	0.3
38	RH4002TA38	Exhaust Deflector	1	0.8
39	RH4002TA39	O-Ring	1	0.2
40	RH4002TA40	Hose Adaptor - 18NPT	1	1.3
41		Hose Adaptor - 19PT		
42	RH4002TA41	Trigger	1	0.6
43	RH4002TA42	O-Ring	1	0.2
44	RH4002TA43	Valve Stem	1	1.2
45	RH4002TA44	O-Ring	1	0.2
46	RH4002TA45	Valve Body	1	2.6
47	RH4002TA46	O-Ring	3	0.2
48	RH4002TA47	Retainer	1	0.3
49	RH4002TA48	Valve Spring	1	0.4
50	RH4002TA49	Spring Pin	2	0.2
51	RH4002TA50	Muffler	1	0.3

HIW-P04500T